



Life Technologies User Bulletin

AuPreP Viral RNA Extraction Miniprep System

For biological fluids containing RNA virus: serum, plasma, body fluids, and cell culture supernatant.

Downstream Application

- Northern, dot and slot blotting
- RT-PCR / Quantitative real-time PCR
- Poly A⁺ RNA selection
- cDNA Synthesis/ Primer extension
- Array analysis
- In vitro translation
- NGS
- Gene editing

Product Contents

Preps	50	250
RXV Buffer	35ml	190ml
WS Buffer	15ml	45ml x 2
RNA Carrier	1	1
Proteinase K	10mg	3x10mg
RNase-free ddH ₂ O	1.5ml x 2	15ml
RNA Mini Column	50	250
Collection Tube	50	250
Protocol	1	1

All buffers need to be mixed well before use.

Shipping & Storage

Life Tech Viral RNA Extraction System is shipped at ambient temperature and stored for up to 6 months.

Protocol

• Please read the following notes before starting the procedure.

WARNING, strong acids and oxidants (for instance, bleach) should not be used together with RXV buffer (because this kind of reaction would produce toxic cyanide)!!!

Important Notes

<Note>: Preheat RNase-free ddH2O to 80°C.

Add 1 ml sterile ddH₂O to each tube to reconstitute the provided Proteinase K by vortexing.
 Store the solution at 4°C.

For RNV-52-904LT: Add 60 ml of ethanol (98-100%) to the WS Buffer bottle when first open the bottle.

For RNV-52-906LT Add 180 ml of ethanol (98-100%) to the WS Buffer bottle when first open the bottle.

The EasyLid is designed to prevent contamination during the procedure.

Twist the arm of the cap and pull the cap to break the EasyLid.



1. Add RNA carrier to RXV Buffer.

proportionally.

Add 1 ml RXV Buffer to the RNA carrier tube, vortex to dissolve and transfer to the RXV Buffer bottle, store at 4°C.

- 2. Pipet 150 μ I sample (serum, plasma, body fluids, and cell culture supernatant) into a 1.5 ml tube.
- 3. Add 570 μI of carrier added RXV Buffer to the sample, mix by vortexing.
 Through mixing is required for sample lysis. If the sample volume is larger than 150 μI, increase the amount of RXV buffer proportionally.
- 4. Add 10 μl Proteinase K to the sample and incubate at room temperature for 10 minutes.
- 5. Add 570 μ I of ethanol (98-100%) to the sample, and mix by vortexing. If the starting sample is larger than 150 μ I, increase the amount of ethanol
- 6. Place a RNA Column in a 2 ml Collection Tube, apply 650 μ l of the ethanol added sample from step 5 to the RNA Column, close the cap, centrifuge at

6,000 x g (8,000 rpm) for 1 minute, and discard the filtrate.

If the solution remains above the membrane, centrifuge again at 13,000 rpm.

7. Repeat step 6 for rest of the sample.

Buffer bottle when first open the bottle.

at full speed (13,000 rpm or 10,000 x g) for 1 minute, and discard the filtrate.

Add 60 ml (for RNV-52-904LT) or 180ml (for RNV-52-906LT) of ethanol (98-100%) to the WS

8. Wash the column twice with 500 μ l of ethanol added WS Buffer by centrifuging

- 9. Centrifuge at full speed for 5 minutes to remove traces of WS Buffer. Residual ethanol may cause the low A_{260}/A_{230} and inhibit reverse transcriptase activity.
- 10. Transfer the column to a RNase-free 1.5 ml tube (not provided), add 50 μl of preheated (80°C) RNase-free ddH₂O, and centrifuge at full speed for 1 minute to elute RNA.
- 11. Store RNA at -70°C.